



## **HG073 USER MANUAL**

# hygger external aquarium LCD display thermometer




**HG073-S** 



**HG073-L** 

## PRODUCT DIAGRAM



- 1) Button: Press once switch between °C/°F
- 2 Low temp within 24 hour
- (3) High temp within 24 hour
- 4 Current temp
- (5) UP button: "+" adjust temperature
- 6 DOWN button: "-" adjust temperature
- 7 SET HI temp: Set high temperature
- (8) SET LO temp: Set low temperature
- 9 Current temp: The display number will flash when the temp out of the preset range

10 SET button:(1) Press once switch between °C/°F;(2)press SET button 5s, the digital SET HI will flash, then press UP button to set the max temperature. Press the SET button to save. (max temp set range 0°C~37°C/32°F~98°F);Then the digital SET LO will flash, press DOWN button to set the min temperature. Press the SET button to save or wait 5s for automatic confirmation. (min temp set range 0°C~36°C/32°F~97°F)

## **PRODUCT FEATURES:**

- 1.Temp measurement range: 0°C~60°C ( 32°F~140°F )
- 2.Temp measurement deviation: ±0.5°C ( ±0.5°F )
- 3. Temp accuracy:  $0.1^{\circ}C(0.1^{\circ}F)$
- 4.Power supply: 3V CR1625\*1 (HG073-S) 3V CR2032\*1 (HG073-L)
- 5. External use on fish tank for saltwater and freshwater/reptiles & amphibians aquariums
- 6. Aluminum alloy sensor and cordless & touch screen design
- 7. Comes with a spare battery
- 8. Recommended replacement of battery half years
- 9.If temp < 0°C, LCD screen will display "LL" and flash; if temp > 60°C LCD screen will display "HH" and flash

## **ATTENTION PLEASE!**


- -It is not recommended to use the product in extreme conditions.

  Otherwise, the internal components of the product may be damaged and cannot be reused after battery replacement.
- -Recommended replace the battery once find the screen is not clean.

-It is not recommended that the temperature difference between high and low temperatures be small. Otherwise, the screen flickers frequently, which results in fast battery consumption.

## **USE INSTRUCTIONS:**

- 1. Product do not immerse the water, it's not water proof.
- 2.Remove the front cover and take out the insulation sheet for first time use or insert the battery into the battery compartment when place the battery. (refer to FIG1)
- 3.Please tear off the 3M adhesive tape and stick the thermometer on the outside of fish tank where it can detect the water temperature. (FIG2~FIG4)
- 4. Please be sure the fish tank has good water circulation to keep the thermometer is correct.



### PACKAGE INCLUDED:

1xthemometer2x button battery (1 installed; 1 spare)1x user manual

### **CONTACT INFORMATION:**

**Distributed by:** Hygger Aquarium, Inc. Chino, CA 91710

Contact us at www.hygger-online.com **Email:** mago@hygger-online.com

Trademarks of Shenzhen Mago Trading Co., Ltd Bantian Group Business Center, Longgang, Shenzhen City, China All Rights Reserved

Made in China